



RHM25280D

NO.	DESCRIPTION	NO.	DESCRIPTION	NO.	DESCRIPTION
1	DUST CAP	40	O-RING	79	SPRING
2	SNAP RING	41	O-RING	80	CARBON BRUSH
3	WASHER	42	HOLDING JACKET	81	INTERNAL CORD
4	SNAP RING	43	SNAP RING	82	SWITCH
5	LOCKING SLEEVE	44	PISTON	83	CORD & PLUG
6	THICK WASHER	45	PISTON O-RING	84	CORD SLEEVE COVER
7	STEEL BALL	46	CYLINDER	85	CORD SLEEVE
8	WASHER	47	CYLINDER PIN WASHER	86	CORD CLAMP
9	SPRING	48	CYLINDER PIN	87	SCREW
10	DRILL BIT COVER	49	O-RING	88	BACK COVER
11	O-RING	50	HOLDER BUSHING	89	CLAMPING BAND
12	OIL SEAL	51	HOLDER	90	T SCREW
13	THRUST RING	52	PRESS FORK	91	SUPPORT CLAMP
14	STRIKER SHAFT	53	O-RING	92	SUPPORT BLOC
15	SCREW	54	BEARING 609Z	93	NUT
16	SPRING WASHER	55	BEARING PRESS PLATE	94	DEPTH GAUGE
17	FRONT HOUSING	56	SCREW	95	AUXILIARY HANDLE
18	OIL SEA	57	GEAR SHAFT	96	NUT
19	BUSHING	58	BEARING 699Z	97	SNAP RING
20	NEEDLE ROLLER BEARING HK3012	59	MODEL SELECTOR FORK	98	WASHER
21	NEEDLE ROLLER BEARING HK0709	60	FORK SPRING	99	KEYLESS CHUCK
22	NINE TEETH WASHER	61	NEEDLE ROLLER BEARING HK0910	100	CHUCK CONNECT SLEEVE
23	SCREW	62	ROCKER BEARING	101	SNAP RING
24	FLAT SNAP RING	63	NEEDLE ROLLER BEARING K15	102	CHUCK CONNECT SHAFT
25	WASHER	64	GEAR	103	STEEL BALL
26	SPRING	65	SPRING	104	SNAP RING
27	O-RING	66	SPRING HOLDER	105	SNAP RING
28	MODEL SELECTOR POLE	67	POSITION WASHER	106	THICK WASHER
29	MODEL SELECTOR	68	ROTOR	107	SPRING
30	SPRING	69	INSULATION WASHER	108	HOLDING BUSH
31	LOCKING BUTTON	70	BEARING 607Z	109	HOLDING BUSH COVER
32	BIG GEARING	71	WIND GUIDE	110	GEAX BOX COVER
33	POSITION PIN	72	SCREW	111	ST4.2X11SELF-TAPPING BOLT
34	CONNECT PIPE	73	STATOR	112	WINGED SCREW
35	PIN	74	INDUCTOR	200	QUICKLY CHANGE CHUCK
36	CLUTCH DISK	75	BEARING BUSH		
37	SNAP RING	76	HOUSING		
38	SNAP RING	77	SWITCH CONTACT		
39	GUIDE BUSH	78	CARBON BRUSH HOLDER		

RHM25280D-EX-UKW230919