


SGM9670P

| NO. | DESCRIPTION | NO. | DESCRIPTION |
|------|------------------------------|-----|-------------------------|
| 1 | LEFT DECORATIVE BLOCK | 25 | CAP NUT |
| 2 | HOUSING | 26 | CHECK VALVE SEAT |
| 3 | O RING | 27 | CHECK VALVE |
| 4 | MOTOR ASSEMBLY | 28 | CASE AIRPROOF RING |
| 5 | GUN SEAT LOCK KNOB | 29 | SUCKER |
| 6 | PIN | 30 | VESSEL |
| 7 | SPRING | 31 | RIGHT DECORATIVE BLOCK |
| 8 | FIXED BLOCK | 33 | SCREW ST3*14 |
| 9 | SCREW ST3*6 | 35 | SCREW ST4*12 |
| 10 | MOTOR SEAT | 36 | CAPACITOR |
| 11 | ADJUST KNOBS | 37 | SWITCH |
| 12 | ADJUST KNOBS PIN | 38 | SWITCH MANDRIL |
| 13 | ADJUST KNOBS SPRING | 39 | SPRING |
| 14 | TRIGGER | 40 | CLEANING BRUSH |
| 15 | O RING | 41 | NOZZLE CLEANING NEEDLE |
| 16 | GUN SEAT | 42 | WIRE COMPONENTS |
| 17 | SPRING | 43 | TERMINAL BLOC |
| 18 | O RING | 44 | CORD ANCHORAGE |
| 19 | VALVE NEEDLE | 45 | CABLE PROTECTOR |
| 20 | NOZZLE Ø2.6 | 46 | CABLE |
| 20-1 | NOZZLE Ø2.2 | 47 | BOTTOM SEAT |
| 20-2 | NOZZLE Ø1.8 | 48 | SCREW ST3*10 |
| 20-3 | NOZZLE Ø1.5 | 49 | WIND SEAT |
| 21 | CHANGE NOZZLE FLOATING BLOCK | 50 | FILTER NET |
| 22 | LEAF SPRING | 51 | REAR COVER |
| 23 | CHANGE NOZZLE | 52 | VISCOSITY MEASURING CUP |
| 24 | WIDTH CONTROL BUTTON | 53 | ADJUSTABLE RING |

SGM9670P-EX-UK240509-1



Sturmax