



## TCM600P, TCM700P

NO.	DESCRIPTION	NO.	DESCRIPTION
1	BOLT	22	HANDLE
2	PLANE WASHER	23	HANDLE COVER
3	SPRING WASHER	24	BASE COVER
4	BOLT	25	SETTING BLOCK
5	SCREW	26	BRACKET
6	NUT	27	BOLT
7	WING NUT	28	BOLT
8	SCALE BOARD	29	NUT
9	ANGLE RULER	30	LEFT ADJUSTMENT BLOCK
10	SLIDER BLOCK	31	BEARING
11	SCREW	32	SCREW
12	PLANE WASHER	33	RIGHT ADJUSTMET BLOCK
13	SPRING WASHER	34	BEARING WASHER
14	NUT	35	BLADE
15	NUT	36	SCREW
16	BOLT	37	BLADE WASHER
17	SCREW	38	BUFFER BLOCK
18	PRESS BLOCK	39	SCREW
19	SOFT PAD	40	BUSH
20	GUIDE RAIL	41	BEARING
21	BASE	42	INSERT OF PRESS BLOCK

UKW231127-1