



TCM9819L

NO.	DESCRIPTION	NO.	DESCRIPTION
1	SCREW	31	WASHER
2	WASHER	32	CAPACITOR BOX
3	BOTTOM GUARD	33	CABLE RING
4	NUT	34	WIRE
5	KNOB NUT	35	COVER PLATE
6	TOP GUARD	36	ANGLE GUAGE
7	NUT	37	MOTOR
8	SCREW	22-34,37	(MOTOR ASSEMBLY)
9	SWITCH	38	TABLE ASSEMBLY
10	CABLE ADAPTOR	39	ADJUSTABLE HANDLE
11	PLUG & CORD	40	WASHER
12	SCREW	41	WASHER
13	NUT	42	SCREW
14	GROUND TERMINAL	43	SPRING WASHER
15	CORD BUSHING PLATE	44	NAMEPLATE
16	SCREW	45	RIVING KNIFE
17	SCREW	46	PRESS PLATE
18	GUAGE LOCKING HANDLE	47	RUBBER FEET
19	WASHER	48	BOX ASSEMBLY
20	GUIDE GUAGE PLATE	49	WASHER
21	GUIDE GUAGE	50	SPRING WASHER
22	PRESS CABLE PIECE	51	SCREW
23	WASHER	52	INNER FLANGE
24	SCREW	53	CUTTER BLADE
25	SCREW	54	OUTER FLANGE
26	SCREW	55	FLUME
27	CAPACITOR BOX COVER	56	SMALL WRENCH
28	CAPACITOR	57	BIG WRENCH
29	SCREW	58	NUT
30	WASHER	59	TOOTH WASHER

TCM9819L-EX-UK210224TC

SturmaxD