



## TCM9820L

NO.	DESCRIPTION	NO.	DESCRIPTION
1	SCREW	27	POWER CORD&PLUG
2	WASHER	28	SCREW
3	BOTTOM GUARD	29	CAPACITOR CLIP
4	BOTTOM GUARD SIDE-PLATE	30	CAPACITOR
5	NUT	31	PRESS PLATE
6	OUTER FLANGE	32	SCREW
7	CUTTER BLADE	33	RIVING KNIFE
8	INNER FLANGE	34	MOTOR FIXING PLATE
9	SCREW	35	SCREW
10	TOP GUARD	36	WASHER
11	NUT	37	RUBBER FEET
12	ADJUSTABLE KNOB	38	CROSS-CUTTING FENCE
13	TABLE ASSEMBLY	39	MOTOR
14	THUMB SCREW	40	MOTOR BRACKET
15	WASHER	41	SCREW
16	RIP FENCE PIN	42	INDICATOR
17	RIP FENCE	43	SCREW
18	SWITCH	44	WATER TANK
19	SWITCH BOX A	45	WASHER
20	CORD CLAMP	46	SWITCH BOX SOLEPLATE
21	SWITCH BOX B	47	SCREW
22	SCREW	48	WASHER
23	PLATE	49	WASHER
24	SCREW	50	NUT
25	RETAINING RING	51	WASHER
26	CORD GUARD		

TCM9820L-EX-UK210406-3

SturmaxD