



TCM9822U

NO.	DESCRIPTION	NO.	DESCRIPTION
1	PUMP	48	RIGHT SUPPORTING BOARD
2	RUBBER COVER	49	NUT
3	CABLE GLOVE	51	RUBBER FEET
4	SWITCH	52	FLAT WASHER
5	SWITCH BOX	53	ROUND-HEAD SCREW
6	TAPPING SCREW	54	HEXAGONAL SCREW
7	CAPACITOR CLIP	55	FLAT WASHER
8	CAPACITOR	56	SPRING WASHER
9	TAPPING SCREW	57	NUT
10	SWITCH BOX COVER	58	SUPPORT PLATE
11	SWITCH BOX COVER WASHER	59	KNOB NUT
12	TAPPING SCREW	60	WATER TROUGH
13	PRESSING-CORD BOARD	61	FLAT WASHER
14	CROSS-HEAD SCREW	62	SCREW
15	CABLE GLAND	63	WATER TANK
16	HANDLE B	64	KNOB
17	SUNK SCREW	65	RUBBER FEET
18A	MOTOR FIXING FRAME	66	SUPPORT LEG
19	INNER GUARD	67	KNOB
20	FLAT WASHER	68	POSITION PIECE
21	CROSS-HEAD SCREW	70	CROSS-HEAD SCREW
22	BLOCKING WATER RING	71	ADJUSTABLE HANDLE
23	INNER FLANGE	72	LEFT ANGLE BOARD
24	BLADE	73	HEXAGON POLE
25	OUTER FLANGE	74	LEFT SUPPORTING BOARD
26	NUT	75	TABLE
27	OUTER GUARD	76	CHAIN
28	FLAT WASHER	77	CROSS-HEAD SCREW
29	SPRING WASHER	78	SPRING WASHER
30	LOCKNUT	80	NUT
31	KNOB NUT	81	SPRING WASHER
32	RIP FENCE	82	M6 PAPILIONACEOUS SCREW NUT
33	SCREW FOR FLANGE	83	SPLINT FOR PROTECTIVE-WATER BOARD
34	NUT	84	PROTECTIVE-WATER BOARD
35	SLIDING PLATE	85	SQUARE NECK SCREW
36	CROSSING-CUTTING FENCE	86	RUBBER NAIL
37	PLATE FOR CROSSING-CUTTING FENCE	87	NUT
38	KNOB	88	PREJUDICIAL ARBOR
39	PLUG	91	BEARING
40	PLASTIC CHAIN	93	MOTOR
42	GUIDE	100	CHAIN SUPPORT PLATE
43	RIGHT ANGLE BOARD	101	INDICATOR
44	SCREW FOR FLANGE	102	FLAT WASHER
45	SCREW	103	SPRING WASHER
46	FLAT WASHER	104	NUT
47	SUNK SCREW		