



engine for TGM1023

NO.	DESCRIPTION	NO.	DESCRIPTION
1	SCREW	27	CYLINDER
2	GASKET	28	MUFFLER GASKET
3	CLUTCH	29	MUFFLER
4	FLAT GASKET	31	FLAT GASKET
5	SCREW	32	SCREW
6	FLAT GASKET	33	AIR INTAKE GASKET
7	CLUTCH BRACKET	34	AIR INTAKE
8	RIGHT CRANKCASE	35	SCREW
9	OIL SEAL	36	CARBURETOR GASKET
10	BEARING	37	CARBURETOR
11	PIN	38	AIR FILTER SEAT
12	CRANKCASE GASKET	39	FILTER
13	CRANKSHAFT ASSY	40	SCREW
14	HALF-CIRCLE KEY	43	AIR FILTER COVER
15	LEFT CRANKCASE	44	AIR FILTER NUT
16	SCREW	45	SCREW
17	FLYWHEEL	46	START ASSY
6	FLAT GASKET	47	SCREW
18	DIAL PLATE	48	SPARK PLUG
19	SIDE COVER	52	CYLINDER COVER
20	SCREW	53	IGNITION COIL
21	NEEDLE BEARING	54	IGNITION COIL GASKET
22	PISTON CIRCLIP	55	SCREW
23	PISTON PIN	56	FUEL TANK
24	PISTON	57	SCREW
25	PISTON RING	58	SCREW
26	CYLINDER GASKET		

TGM1023-EX-UK241009

Sturmax

SturmaxD

TGM1023

NO.	DESCRIPTION	NO	DESCRIPTION
1	ENGINE ASSEMBLY	17	PLATEN
2	DRUM	18	NUT
3	OIL MOUTH	19	UPPER BATTEN
4	TRANSMISSION CASE	20	UPPER BLADE
5	PIN	21	LOWER BLADE
6	BEARING	22	ANTI WEAR PAD
7	CIRCLIP	23	LOWER BATTEN
8	ANTI WEAR PAD	24	SCREW
9	SCREW	25	SCREW
10	GEAR SHAFT	26	BLADE COVER
11	CONNECTION ROD	27	REAR HANDLE ASSEMBLY
12	GEAR	28	SCREW
13	FIXED CLIP	29	NUT
14	SEAL	30	HANDLE ASSEMBLY
15	TRANSMISSION CASE COVER	31	ESCAPE-PIPE
16	SCREW		

TGM1023-EX-UK241009

SturmaxD

SturmaxD

