



## CC-9918BE

NO.	DESCRIPTION	NO.	DESCRIPTION
1	CABLE	30	O-RING
2	CABLE PROTECTOR	31	OIL TANK COVER
3	CABLE ANCHORAGE	32	TUBING
4	SCREW ST4*12	33	SEALING RING
5	CAPACITOR	34	FUEL TANK JOINT
6	SWITCH	35	GEAR BOX
7	SAFETY LOCKING BUTTON	36	BEARING 608Z
8	SPRING	37	BIG GEAR
9	SPRING	38	OUTPUT SHAFT
10	SWITCH TRIGGER	39	BEARING 6000RS
11	BEARING 6001Z	40	GEAR BOX COVER
12	ROTOR	41	OIL PUMP COMPONENTS
13	BEARING 607Z	42	TUBING
14	BEARING COVER	43	RIGHT HOUSING
15	WIND GUIDE	44	SPRING
16	SCREW ST5*50	45	CHAIN WHEEL
17	STATOR	46	CIRCLIP $\Phi 7$
18	O-RING	47	RUBBER RING
19	OIL NOZZLE	48	FIXED PLATE
20	LEFT HOUSING	49	TENSIONING BLOCK
21	CARBON BRUSH	50	TENSIONING SCREW M5X45
22	BRUSH HOLDER	51	GUIDE BAR
23	SCREW ST3*8	52	CHAIN
24	REAR COWL	53	SCABBARD
25	SCREW ST4*16	54	RUBBER RING
26	PROTECTIVE PLATE	55	CHAIN COVER
27	OIL TANK	56	LOCATING SLEEVE
28	CHECK VALVE	57	NUT M8
29	POTHOOK	58	WRENCH

BM-UK240506