



CD-31121, CD-31122, CD-3118

NO.	DESCRIPTION	NO.	DESCRIPTION
1	CHUCK SCREW	22	THE SECOND PLANETARY GEAR
2	CHUCK	23	TWO SPEED CHANGE RING
3	TORQUE ADJUSTMENT RING	24	THE FIRST PLANETARY GEAR CARRIER
4	TORQUE ADJUSTMENT NUT	25	THE FIRST PLANETARY GEAR
5	SPRING	26	FIXED GEAR RING
6	WASHER	27	MOTOR GEAR
7	CIRCLIP	28	WASHER
8	WASHER	29	SCREW
9	STEEL BALL	30	MOTOR PRESS BOARD
10	WASHER	31	MOTOR
11	BUSH	32	INTERNAL CABLE
12	STEEL BALL	33	LED
13	FRONT GEAR BOX	34	TORQUE SPRING
14	SPINDLE	35	TWO SPEED CHANGE BUTTON
15	GEAR RING	36	HOUSING
16	THE THIRD PLANETARY GEAR	37	SCREW
17	WASHER	38	STRAP
18	THE SECOND PLANETARY GEAR CARRIER	39	DIRECTION LEVEL
19	REAR GEAR BOX	40	SWITCH
20	TWO SPEED CHANGE LEVEL	41	BATTERY PACK
21	SCREW	888	GEAR BOX ASSEMBLY

UK-BM20151228