

GC-99450

No.	DESCRIPTION	No.	DESCRIPTION
1	IGNITION COIL	46	TRIGGER PIN
2	SCREW M5X20	47	TRIGGER
3	FLYWHEEL	48	TRIGGER CONTROLLER
4	NUT M8	49	TRIGGER SPRING
5	COOLING-AIR MASK	50	HANDLE COVER
6	3 HOLES WASHER	51	ACCELERATOR ROD
7	STARTER	52	DUST BLOCK
8	SCREW M5X14	53	THROTTLE LEVER ANTI-VIBRATION BLOCK
9	SCREW M4X10	54	THROTTLE LEVER
10	OIL SEAL COVER	55	THROTTLE LEVER GUIDE
11	OIL SEAL COVER 15X35X4.5	56	OIL SEAL 15X28x4.5
12	RING Ø35	57	OIL PUMP
13	SCREW M5X30	58	OIL PUMP COVER PLATE
14	DUST PLATE	59	WORM
15	SCREW 4.8X16	60	CHAIN WHEEL
16	ANTI-VIBRATION CUSHION	61	NEEDLE BEARING 12X15X14.5
17	LEFT CRANKCASE	62	CLUTCH PLATE
18	ANTI-SHOCK BLOCK	63	CLUTCH WASHER
19	FLAMEOUT SWITCH RETAINER	64	CLUTCH
20	DOUBLE LIGHT	65	BRAKE GUARD
21	FLAMEOUT SWITCH	66	NUT M8
22	SCREW M5X10	67	GUIDE BAR COVER
23	BEARING 6202	68	SAW CHAIN
24	CRANKCASE GASKET	69	GUIDE BAR
25	SEMICIRCLE KEY 3X3.7X10	70	FRONT HANDLE
26	CRANKSHAFT	71	OIL NOZZLE COVER PLATE
27	NEEDLE BEARING 11X15X12.5	72	CHAIN GUIDE BLOCK
28	PIN 5X10	73	SCREW
29	RIGHT CRANKCASE	74	OIL NOZZLE
30	ANTI-SHOCK BLOCK	75	SPIKED BUMPER
31	BALANCER BODY	76	AERATION NOZZLE CLIP
32	BALANCER BASE	77	AERATION NOZZLE
33	FUEL TUBE	78	SUCTION NOZZLE CLIP
34	FUEL FILTER	79	SUCTION TUBE
35	BOLT	80	SUCTION NOZZLE
36	DUST PLATE	81	OIL TUBE
37	SELF-LOCK SWITCH	82	SCREW M5X50
38	TORSION ROD SPRING	83	AIR INTAKE TUBE PROTECT
39	TORSION ROD SHAFT	84	AIR INTAKE TUBE
40	FUEL CAP	85	SCREW M5X41
41	FUEL FLAP WASHER	86	CARBURETOR
42	ANTI-VIBRATION CUSHION	87	RETAINER
43	FUEL CAP RETAINER	88	AIR INTAKE FLANGE
44	FUEL TANK	89	AIR INTAKE TUBE SUPPORT GASKET
45	SCREW 5x16	90	SPARK PLUG

GC-99450

No.	DESCRIPTION	No.	DESCRIPTION
91	CYLINDER	65-6	TIGHTENER GEAR
92	UPPER COVER PLATE	65-7	RIGHT COVER
93	AIR FILTER	65-8	RIGHT COVER ANTI-SHOCK BLOCK
94	AIR FILTER COVER	65-9	BRAKE CONTROL ROD
95	AIR FILTER LOCK NUT WASHER	65-10	SECONDARY PULL-ROD
96	AIR FILTER LOCK NUT	65-11	MAIN PULL-ROD
97	NUT M5	65-12	FRONT GUARD PIN
98	MUFFLER COVER	65-13	SHIELD RING 3
99	MUFFLER	65-14	FRONT GUARD
100	MUFFLER GASKET	65-15	CAM PLATE
101	SCREW M5X90	65-16	CAM PLATE WASHER 6X22x1.5
102	CYLINDER GASKET	65-17	CAM PLATE PIN
103	AIR INTAKE TUBE WASHER	65-18	BRAKE SPRING
104	AIR INTAKE TUBE	65-19	FLAT WASHER Ø6
105	AIR INTAKE TUBE HOLDER	65-20	SHIELD RING Ø5
106	HEAT INSULATION GASKET	65-21	RUBBER WASHER 5X10X2.5
107	IDLE ADJUSTING GUIDE	65-22	FRONT GUARD PIN SET
108	OIL FILTER BODY	65-23	PIN 3X8
109	CHAIN CATCHER BLOCK	65-24	SHIELD RING 4
110	CONICAL SPRING BASE	65-25	TIGHTENER
111	CONICAL SPRING	65-26	TIGHTENER SCREW
112	PISTON RING	65-27	MAIN BRAKE SPRING
113	PISTON	65-28	SECONDARY BRAKE SPRING
114	PISTON PIN	92-1	UPPER COVER PLATE
115	NEEDLE BEARING RING	92-2	WIND SHELTER SLICE
116	PISTEN PIN RING		
117	OIL CAP PACKING WASHER		
118	OIL CAP		
7-1	STARTING HANDLE		
7-2	STARTER COVER		
7-3	STARTER ROPE		
7-4	STARTER COIL SPRING		
7-5	STARTER COIL SPRING SHELL		
7-6	STARTER WHEEL		
7-7	ENERGY STORAGE SPRING		
7-8	RATCHET		
7-9	FLAT WASHER		
64-1	RETAINER		
64-2	SHOE BLOCK		
64-3	CLUTCH EXTENSION SPRING		
65-1	PROTECTING GUARD		
65-2	SCREW ST4X8		
65-3	BRAKE SPRING COVER		
65-4	BRAKE BELT		
65-5	TIGHTENER COVER		

