



BO-4212

NO.	DESCRIPTION	NO.	DESCRIPTION	NO.	DESCRIPTION	NO.	DESCRIPTION	NO.	DESCRIPTION
1	SCREW M4X20	42	SEALING WASHER	89	CONNECTOR	129	WASHER	169	LID
2	OUTSIDE COVER	44	SCREW	90	NUT	130	SCREW	170	NOZZLE
3	FILTER CORE	45	SCREW ASSEMBLY	91	PULLING ROD	131	CLIP	171	NOZZLE PIECE
4	DEFENDER FOR FILTER CORE	46	INLET TUBE	92	COTTER	132	TUBE	172	NOZZLE PIECE COVER
5	INSIDE COVER	47	GASKET	93	NET COVER	133	CHEMICAL TANK LID	173	SCREW
7	CARBURETTOR	48	INSULATOR	95	PIPE	134	AIR VALVE	179	CLIP
8	SCREW	49	CYLINDER	97	SCREW	135	SEALING WASHER	180	TUBE
9	WINDING	50	COVER	98	PIN	136	TUBE	181	SWITCH ASSEMBLY
10	IGNITION	51	SCREW ASSEMBLY	99	RUBBER PLATE	137	FILTER	182	CLAMP
11	SCREW	52	CAP	100	SLIDE	138	CHEMICAL TANK	183	CONNECTION PIPE
12	SPRING	53	SPARK PLUG	101	SUPPORT ARM	139	SEALING WASHER	185	FUEL TANK
13	SPARK PLUG CAP	54	GASKET	102	RING	140	LINK PIPE	186	SCREW
14	NUT	55	GASKET	103	SHUTTER	141	CONNECTOR LID	187	BOTTOM
15	WASHER	56	MUFFLER	104	PLUG	142	TUBE	188	SPRING
16	WASHER	58	SCREW	105	ROCKER SHAFT	143	MISTING PLATE	189	LOCK PIN
17	ROTOR	59	SCREW ASSEMBLY	106	SEALING WASHER	144	SEALING WASHER	190	THROTTLE TRIGGER
18	SCREW	60	NUT	107	PIN	145	CLAMP BOARD	191	SPRING
19	SCREW	61	WASHER	108	RING	146	BOLT	192	RIGHT BOX
20	HANDLE SEATING	62	SPRING WASHER	109	BOLT	147	WASHER	193	SCREW
21	FRONT CRANKCASE	63	FRAME	110	FUEL TANK SUPPORT	148	NUT	194	SCREW ASSEMBLY
22	NUT	65	RUBBER PIN	111	BACK VOLUTE CASE	149	SCREW ASSEMBLY	195	CABLE
24	SCREW	66	CLIP	112	RUBBER PILLAR	150	CHEMICAL TANK DOWN LID	196	TUBE
25	CABLE FIXITY	67	BACK MAT	113	BOLT	151	DOWN PLATE	197	STOP SWITCH ASSEMBLY
26	SEALING WASHER	69	SCREW ASSEMBLY	114	IMPELLER	152	DUST PLATE	198	SAFETY LEVER
27	SEAL	70	SUPPORT	115	FRONT VOLUTE CASE	154	BEND PIPE	199	SPRING
28	BEARING	72	WASHER	116	NUT	155	CLIP ASSEMBLY	200	NUT
29	CRANKSHAFT	73	WASHER	117	NUT	156	HOSE	201	LEFT BOX
30	BACK CRANKCASE	74	BELT COMPONENT	118	LONG SCREW	157	CLIP ASSEMBLY		
31	RATCHET	75	SOCKET WRENCH	119	SCREW	158	CONNECTOR		
32	WASHER	77	SPANNER	120	SCREW	159	SEALING WASHER		
33	STARTER	78	SCREW	121	SCREW	160	PIPE		
34	BOLT	79	CLIP	122	PROTECTION	161	CONNECTOR ASSEMBLY		
35	KEY	80	INSURANCE CHAIN	123	FUEL TANK ASSEMBLY	162	LONG BEND PIPE		
37	NEEDLE BEARING	81	SUPPORT FRAME	124	FUEL TANK LID ASSEMBLY	163	NOZZLE ASSEMBLY		
38	RING	82	PLATE	125	FUEL TANK LID	164	VALVE		
39	PISTON PIN	86	HANDLE	126	FILTER NET	165	SEALING WASHER		
40	PISTON	87	GRADUATOR	127	LID	166	SHOT PIPE		
41	PISTON RING	88	DUST ROD	128	FILTER NET ASSEMBLY	167	SCREW		