

ГК-35180Д

NO.	DESCRIPTION	NO.	DESCRIPTION	NO.	DESCRIPTION
1	DOWN FLANGE	38	STEEL TUBE B	B8	BEARING 6002RS
2	BLADE	39	CABLE CLAMP	B9	BEARING 6000RS
3	UPPER FLANGE	40	LEFT HANDLE	B10	BOLT M6X10
4	FLANGE COVER	41	SAFETY ROD	B11	SCREW M6X20
6	SPINDLE	42	SPRING	B12	BEARING 609RS
7	BIG GEAR	43	SWITCH TRIGGER	B13	CIRCLIP 10
8	SEAL RING	44	SPRING	B14	CIRCLIP 24
9	GEAR BOX	45	SWITCH	B15	WASHER 6
11	PINION SHAFT	46	RIGHT HANDLE	B16	SCREW ST4.2X12
12	PLASTIC SPANNER	47	SHOULDER STRAP	B17	SCREW M6X25
13	JAM	48	CABLE	B18	SPRING WASHER 6
14	SQUARE HEAD SCREW	50	SOFT SHAFT COUPLER	B19	WASHER 6
15	SPOOL COVER	51	GEAR BOX COVER	B20	RIVET 4X6
16	NYLON LINE	52	SMALL GEAR SHAFT	B22	SPRING WASHER 4
17	BASE OF NYLON LINE	53	MOTOR FRONT BRACKET	B23	WASHER 4
18	SPRING	54	ROTOR	B25	SCREW M5X25
19	BOX OF NYLON LINE	55	STATOR	B26	NUT M5
20	BUSH	56	CARBON BRUSH HOLDER	B27	SCREW M5X32
21	HEXAGONAL SHAFT	57	CARBON BRUSH	B28	SCREW ST4.2X15
22	DOWN GUARD	58	MOTOR BACK BRACKET	B29	PIN Ø3X18
23	BLADE	59	FAN	B30	SCREW M4X12
24	GUARD	60	HOUSING	B31	CIRCLIP 10
25	GUARD PRESS BOARD	63	TERMINAL BLOCK	B32	BEARING 6900Z
26	STEEL TUBE ASSEMBLY	64	RUBBER LINE	B33	NEEDLE BEARING HK0608
26.1	TOOL CIRCLIP	65	CABLE SLEEVE	B34	SCREW M5X55
26.2	STEEL TUBE	66	CABLE & PLUG	B35	BEARING 6000Z
26.3	PLASTIC TUBE(1124MM)	68	SWITCH TRIGGER JAM	B36	BEARING 608Z
26.4	PLASTIC TUBE B(118MM)	69	SAFETY LOCKING BUTTON JAM	B37	SCREW ST2.9X10
26.5	BUSH	71	TORSIONAL SPRING	B38	CIRCLIP 6
27	SOFT SHAFT	72	CABLE HOOK	B39	SCREW ST4.2X15
33	RUBBER HANDLE	B2	NUT M10X1.25	100	GEAR BOX ASSMEBLY
34	STEEL TUBE A	B4	SCREW M5X12	101	SPOOL ASSEMBLY
35	DOWN HANDLE CLAMP	B5	SPRING WASHER 5	102	MOTOR ASSEMBLY
36	HANDLE SUPPORT	B6	WASHER 5	103	GUARD ASSEMBLY
37	UPPER HANDLE CLAMP	B7	CIRCLIP 32		