



## ГК-35380

NO.	DESCRIPTION	NO.	DESCRIPTION
1	CARRING HANDLE	38	POLE Ø6X263
2	UP CAP	39	TORTILE SPRING
3	TAPPING SCREW ST4.2X16	40	FLAP
4	BRUSH ASSEMBLE	41	INNER CIRCLIPS D8
5	TAPPING SCREW ST4.2X60	42	FIXER
6	MOTOR CAP A	43	BASKETRY HANDLE
7	BALL BEARING 628RS	44	BASKETRY
8	ARMATURE	45	BEND PIPE
9	STATOR	46	U PIPE
10	BALL BEARING 6000RS	47	KNOB
11	MOTOR CAP B	48	BOLT M6X45
12	FAN	49	CABLE CLIP
13	BELT WHEEL- A	50	CABLE
14	MOTOR SEAT	51	PLUG& CORD
15	TAPPING SCREW ST4.8X22	52	BUTTON
16	BREAK RING	53	RETURN SPRING I
17	CAP	54	UP BOX
18	C RING D9	55	TRIGGER
19	BALL BEARING 609RS	57	DOWN BOX
20	BALL BEARING 6002RS	58	TAPPING SCREW ST4.2X19
21	BAND BRAKE	59	CORD ARMOR
22	BREAK SPRING	60	MAIN SWITCH
23	BLADE DRIVER	61	CORD CLAMP
24	BELT WHEEL- B	62	RETURN SPRING II
25	TAPPING SCREW ST4.2X13	63	WHEEL SHAFT-F
26	WASHER D4	64	PULL SPRING
27	ROUNDED COVER	65	WASHER Ø6.3XØ16.7X1.2
28	RIBBED BELT	66	SPONGE
29	BLADE ORIENTING	67	ADHESIVE TAPE
30	BLADE	68	LOGO LABEL
31	BLADE SCREW M8X20	69	WARNING LABEL
32	BASE	70	DATA LABEL
33	WHEEL SHAFT-B	888	SWITCH BOX ASSEMBLY
34	BACK WHEELH5	889	MOTOR ASSEMBLY
35	WHEEL CAP		
36	FRONT WHEEL		
37	CORD CLAMP		