



ДУ-21400

NO.	DESCRIPTION	NO.	DESCRIPTION
1	SCREW M5X20(LEFT)	3-20	PLANET GEAR
2	CHUCK	3-21	WASHER
3	GEAR BOX ASSEMBLY	3-22	MIDDLE COVER
3-1	TAPPING SCREW	4	BEARING 608ZZ
3-2	PRESSURE PLATE	5	ARMATURE
3-3	TORQUE ADJUSTMENT RING	6	BEARING 626ZZ
3-4	TORQUE CUP	7	STATOR
3-5	SCREW RING	8	CARBON CAP
3-6	TORQUE SPRING	9	CARBON BRUSH
3-7	CIRCLIP FOR SHAFT	10	BRUSH HOLDER
3-8	WASHER	11	INDUCTOR
3-9	STEEL BALL	12	CONDENSER
3-10	STEEL BUSH	13	SWITCH
3-11	WASHER	14	SCREW ST4X11
3-12	STEEL BALL	15	CORD CLIP
3-13	GEAR BOX ENCLOSURE	16	RUBBER SLEEVE
3-14	SPRING PIECE	17	CORD
3-15	OUTPUT SHAFT	19	NAME PLATE
3-16	COLUMN PIN	20	SCREW ST3X16
3-17	GEAR	21	FORWARD/REVERSE LEVER
3-18	GEAR RING	22	SEALING RING
3-19	CENTER GEAR	888	HOUSING ASSEMBLE

EN-UK20180205