



ДШ-3112ЛБ, ДШ-3118ЛБ

| NO. | DESCRIPTION | NO. | DESCRIPTION |
|-----|-----------------------------------|-----|-----------------------------|
| 1 | CHUCK SCREW | 27 | INNER GEAR RING |
| 2 | CHUCK | 28 | MOTOR GEAR |
| 3 | TORQUE ADJUSTMENT RING | 29 | WASHER |
| 4 | TORQUE ADJUSTMENT NUT | 30 | SCREW |
| 5 | SPRING | 31 | MOTOR PRESS BOARD |
| 6 | WASHER | 32 | MOTOR |
| 7 | SPINDLE | 33 | INTERNAL CABLE |
| 8 | BEARING 688Z | 34 | SHRAPNET |
| 9 | STEEL BALL | 35 | TWO SPEEDS CHANGE BUTTON |
| 10 | PIN | 36 | SPRING |
| 11 | GEAR BOX | 37 | DRCORATION COVER |
| 12 | BEARING 688Z | 38 | LOCK RING |
| 13 | CIRCLIP | 39 | HOUSING |
| 14 | THE THIRD PLANET BRACKET | 40 | SCREW |
| 15 | GEAR RING | 41 | ROPE |
| 16 | WASHER | 42 | SWITCH |
| 17 | THE THIRD PLANETARY GEAR | 43 | DIRECTION SWITCH |
| 18 | THE SECOND PLANETARY GEAR CARRIER | 44 | BUCKLE |
| 19 | THE SECOND PLANETARY GEAR | 45 | SCREW BIT HOLDER |
| 20 | TWO SPEED CHANGE GEAR RING | 46 | SCREW BITS |
| 21 | PLASTIC GEAR RING | 47 | SPRING |
| 22 | SCREW | 48 | MAGNET (ONLY FOR ДШ-3118ЛБ) |
| 23 | SPINDLE LOCK BLOCK | 49 | BATTERY PACK |
| 24 | LOCK PIN | 50 | CHARGER |
| 25 | THE FIRST PLANETARY GEAR CARRIER | 888 | GEAR BOX ASSEMBLY |
| 26 | THE FIRST PLANETARY GEAR | 889 | MOTOR ASSEMBLY |

UK-EN20190821