



## ДШ-3112ЛЭ

NO.	DESCRIPTION	NO.	DESCRIPTION
1	CHUCK SCREW	23	TWO SPEED CHANGE BUTTON
2	KEYLESS CHUCK	24	SPRING
3	TORQUE ADJUSTMENT RING	25	THE FIRST PLANETARY GEAR BRACKET
4	TORQUE ADJUSTMENT NUT	26	THE FIRST PLANETARY GEAR
5	TORQUE ADJUSTMENT SPRING	27	INNER GEAR RING
6	TORQUE ADJUSTMENT WASHER	28	WASHER
7	SPINDLE	29	MOTOR GEAR
8	BEARING 688Z	30	SCREW
9	STEEL BALL	31	PRESS BOARD
10	PIN	32	MOTOR
11	GEAR BOX	33	INTERNAL WIRE
12	BEARING 688Z	34	TORQUE POSITION SPRING
13	CIRCLIP	35	DIRECTION POLE
14	THE THIRD PLANETARY GEAR BRACKET	36	SWITCH
15	GEAR RING	37	HOUSING
16	WASHER	38	SCREW
17	THE THIRD PLANETARY GEAR	39	HOUSING CIRCLIP
18	THE SECOND PLANETARY GEAR BRACKET	40	BATTERY PACK
19	THE SECOND PLANETARY GEAR	41	CHARGER
20	TWO SPEED CHANGE GEAR RING	998	MOTOR ASSEMBLY
21	RIVET	999	GEAR BOX ASSEMBLY
22	TWO SPEED CHANGE RING		

UK-EN20160902