



ЛБ-4080Б

NO	DESCRIPTION	NO	DESCRIPTION
1	Tapping screw ST3.9×17	25	CirclipØ6
2	Housing	26	Shaft sleeve
3	Transparence gurad	27	Washer
4	Screw M5*12	28	Big GEAR
5	Base plate press board	29	Balance plate
6	Base plate assembly	30	Support plate
7	Pin φ4×24	31	Needle bearing K060913
8	Eccentric gear	32	Center bracket
9	Washer	33	Bearing 608Z
10	Blade guide support assembly	34	Spring
11	Washer	35	Switch lock knob
12	Washer	36	Variable speed switch
13	CirclipØ6	37	Switch
14	Steel Ball Φ4	38	rotor
15	Spring	39	Carbon brush
16	Pendulum switch knob	40	Brush holder
17	Steel wire	41	Bearing 607Z
18	Spring	42	Stator
19	spring housing	43	Cable protector
20	Reciprocate rod	44	Cable
21	Reciprocate rod gasket	45	Allen key
22	Pin φ4×27	46	Dust outlet
23	Base holder	47	Screw M5×8

UK-EN20180625