



## BS8573

NO.	DESCRIPTION	NO.	DESCRIPTION
2	SANDING BELTS	29	WASHER
3	BOTTOM PLATE	30	ADJUST-NUT
4	BODY	31	SCREW
5	FRONT-WHEEL FRAME	32	STATOR
6	BIG SPRING	33	SCREW
7	SMALL SPRING	34	FAN BAFFLE
8	REAR-WHEEL	35	ROTOR
8-1	ROLLER PIN	36	SCREW
9	WASHER	37	BEARING COVER
10	NEEDLE BEARING	38	BEARING 608Z
11	GEAR COVER	39	INNER COVER
12	BEARING 626Z	40	SCREW
13	BIG GEAR	41	GEAR AXIS
14	CIRCLIP	42	BAFFLE
15	BRUSH BUSH	43	BEARING 627Z
16	BRUSH HOLDER	44	SCREW
18	CARBON-BRUSH	45	SMALL-BELT-WHEEL
19	BEARING 626Z	46	BELT
20	BEARING BUSH	47	BIG-BELT-WHEEL
21	INDUCTOR	48	BELT COVER
22	CIRCLIP	49	SCREW
23	WASHER	50	NAME PLATE
24	SWITCH	51	CABLE SLEEVE
25	CAPACITOR	52	CABLE&PLUG
26	SCREW	888	HOUSING ASSEMBLE
27	CABLE CLAMP		

ST20121129-02

POWER • GAS • HAND • TOOLS

Sturmi!  
POWER • GAS • HAND • TOOLS