



PE-2510B

NO.	DESCRIPTION	NO.	DESCRIPTION	NO.	DESCRIPTION
1	FRONT COVER	29	CIRCLIP Φ 47	57	TAPPING SCREWST4X16
2	CIRCLIP FOR SHAFT Φ 28	30	BEARING 6303-2RS	58	CORD ANCHORAGE
3	ELASTIC COLLAR	31	"O" RING Φ 51 \times Φ 2	59	CORD GUARD
4	GLID CLIP	32	CRANKCASE	60	POWER CORD AND PLUG
5	SPRING WASHER	33	ANTI-SHOCK COVER	62	SCREW M8X35
6	SPRING	34	WASHER Φ 12 \times 2.5	63	NUT M8
7	STEEL COLUMN Φ 8X19.5	35	ANTI-SHOCK SPRING	64	"O" RING Φ 19 \times Φ 2
8	BASE	36	ANTI-SHOCK WASHER	65	HANDLE CAP
9	ADJUSTMENT RING	37	BOLT M10X55	66	WIND OUTLET
10	RUBBER SHEATH	38	COLLAPSIBLE	67	MOTOR HOUSING
11	CYLINDER-SLEEVE	39	BIG GEAR	68	WASHER Φ 5
12	SCREW M6X25	40	NEEDLE BEARING BK1210	69	SCREW M5X55
13	SPRING WASHER Φ 6	41	CIRCLIP Φ 14	70	WIND OUTLET
14	"O" RING Φ 49 \times Φ 2	42	AIRPROOF GASKET	71	BRUSH HOLDER
15	ASSISTANT HAMMER	43	GEAR BOX	72	CARBON BRUSH
16	O RING Φ 23.4 \times Φ 3.5	44	SPRING WASHER Φ 5	73	BRUSH CAP
17	CYLINDER	45	SCREW M5X20	74	SCREWM5X6
18	RAM	46	HAMMER THROWER	75	RUBBER NAIL Φ 4
19	O RING Φ 23.4X3.5	47	BEARING 6201-NSK	76	END COVER
20	O RING Φ 23.4X3.5	48	"O" RING Φ 36 \times Φ 2	77	SCREWM5X50
21	PIN OF PISTON	49	ROTOR	78	TAPPING SCREWST4X19
22	PISTON	50	BEARING 608-2Z	80	CAP OF HANDLE
23	OIL STORAGE CAP	51	WIND GUIDE	81	CLIP OF HANDLE
24	"O" RING Φ 59 \times Φ 2	52	TAPPING SCREWST4.8X55	82	BASE OF AUXILIARY HANDLE
25	CONNECTING BAR	53	STATOR	83	NUT
26	NEEDLE BEARING HK1212	54	CAPACITOR	84	AUXILIARY HANDLE
27	CRANK	55	SWITCH	100	AUXILIARY HANDLE ASSEMBLY(81...+84)
28	WOODRUFF KEY 4X12	56	INDUCTOR	888	HANDLE ASSEMBLY

EN20110511