



PE-2526Д

NO.	DESCRIPTION	NO.	DESCRIPTION	NO.	DESCRIPTION
1	DUST CAP	38	SNAP RING	75	BEARING BUSH
2	SNAP RING	39	GUIDE BUSH	76	HOUSING
3	WASHER	40	O-RING	77	SWITCH CONTACT
4	SNAP RING	41	O-RING	78	CARBON BRUSH HOLDER
5	LOCKING SLEEVE	42	HOLDING JACKET	79	SPRING
6	THICK WASHER	43	SNAP RING	80	CARBON BRUSH
7	STEEL BALL	44	PISTON	81	INTERNAL CORD
8	WASHER	45	PISTON O-RING	82	SWITCH
9	SPRING	46	CYLINDER	83	CORD & PLUG
10	DRILL BIT COVER	47	CYLINDER PIN WASHER	84	CORD SLEEVE COVER
11	O-RING	48	CYLINDER PIN	85	CORD SLEEVE
12	OIL SEAL	49	O-RING	86	CORD CLAMP
13	THRUST RING	50	HOLDER BUSHING	87	SCREW
14	STRIKER SHAFT	51	HOLDER	88	BACK COVER
15	SCREW	52	PRESS FORK	89	CLAMPING BAND
16	SPRING WASHER	53	O-RING	90	T SCREW
17	FRONT HOUSING	54	BEARING 609Z	91	SUPPORT CLAMP
18	OIL SEA	55	BEARING PRESS PLATE	92	LOCKING BUTTON SPRING
19	BUSHING	56	SCREW	93	LOCKING BUTTON
20	NEEDLE ROLLER BEARING HK3012	57	GEAR SHAFT	94	DEPTH GAUGE
21	NEEDLE ROLLER BEARING HK0709	58	BEARING 699Z	95	AUXILIARY HANDLE
22	NINE TEETH WASHER	59	MODEL SELECTOR FORK	96	NUT
23	SCREW	60	FORK SPRING	97	SNAP RING
24	FLAT SNAP RING	61	NEEDLE ROLLER BEARING HK0908	98	WASHER
25	WASHER	62	ROCKER BEARING	99	KEYLESS CHUCK
26	SPRING	63	NEEDLE ROLLER BEARING K15	100	CHUCK CONNECT SLEEVE
27	O-RING	64	GEAR	101	SNAP RING
28	MODEL SELECTOR POLE	65	SPRING	102	CHUCK CONNECT SHAFT
29	MODEL SELECTOR	66	SPRING HOLDER	103	STEEL BALL
30	SPRING	67	POSITION WASHER	104	SNAP RING
31	LOCKING BUTTON	68	ROTOR	105	SNAP RING
32	BIG GEARING	69	INSULATION WASHER	106	THICK WASHER
33	POSITION PIN	70	BEARING 607Z	107	SPRING
34	CONNECT PIPE	71	WIND GUIDE	108	HOLDING BUSH
35	PIN	72	SCREW	109	HOLDING BUSH COVER
36	CLUTCH DISK	73	STATOR	200	QUICKLY CHANGE CHUCK
37	SNAP RING	74	INDUCTOR		

UK-EN20170327