

CF7326P

NO.	DESCRIPTION	NO.	DESCRIPTION	NO.	DESCRIPTION
1	HEX BOLT	28	HEX BOLT	55	DUST COVER
2	FLAT WASHER	29	CIRCLIP FOR SHAFT	56	HEX BOLT
3	COVER FOR FEED BELT	30	VICE SCREW COVER	57	MITRE GAUGE
4A	FEED BELT	31	CLAMP BASE	58	PIN
5	SMALL WHEEL	32	PIN	59	TRUCKLE
6	WOODRUFF KEY	33	V PIN	60	V PIN
7	MOTOR	34	VICE SCREW	61	BASE
8	HEX BOLT	35	HEX BOLT	62	DEPTH LIMITER
9	FLAT WASHER	36	PRESS BOARD OF THE VICE SCREW	63	NUT
10	SWITCH	37	HANDWHEEL	64	CORD & PLUG
11	CABLE	38	SMALL HANDLE	7-1	LEFT COVER OF MOTOR
12	SWITCH BASE	39	HEX BOLT	7-2	BREAK PAD
13	BOLT	40	SIDE COVER	7-3	BEARING
14	HEX BOLT	41	HEX BOLT	7-4	ROTOR WITH FAN
15	FLAT WASHER	42	FLAT WASHER	7-5	BEARING
16	SUPPORT OF COVER FOR FEED BELT	43	OUTER WASHER	7-6	STATOR
17A	BIG WHEEL	44	INNER WASHER	7-7	RIGHT COVER OF MOTOR
18	PIN	45	HEX BOLT	7-8	FAN REAR COVER
19	MAIN SHAFT	46	FLAT WASHER	7-9	ENCLOSURE
20	BEARING COVER	47	GUARD	7-10	STARTING CAPACITOR
21	BEARING6205-2RS	48	SPRING	7-11	CAPACITOR COVER
22	HANDLE	49	PIN	7-12	RUNNING CAPACITOR
23	SWING ARM	50	HEX BOLT	7-13	CAPACITOR COVER
24	BEARING6205-2RS	51	BRACKET	7-14	TERMINAL
25	BEARING COVER	52	HEX BOLT	7-15	MOTOR GUARD
26	NUT	53	FLAT WASHER		
27	HEX BOLT	54	BOLT		

ST20101208-1

