



УШМ-9012ПМ

NO.	DESCRIPTION	NO.	DESCRIPTION
11	OUT FLANGE	29	BEARING COVER
2	GUARD	30	WIND GUIDE
4	INNER FLANGE	31	TAPPING SCREW ST4.2*70
5	SPINDLE	32	WASHER
6	KEY 3*10	33	STATOR
7	ANTI-DUST COVER	34	HOUSING
8	SCREW M4*12	35	SWITCH
9	GEAR BOX COVER	36	CABLE SLEEVE
10	BEARING 6201	37	DECORATION RING
11	SCREW M4*8	38	REAR COVER
12	BIG GEAR	39	COVER
13	CIRCLIP 12#	40	TAPPING SCREW ST4.2*14
14	NEEDLE BEARING HK0808	41	CABLE
15	CIRCLIP 6#	42	TAPPING SCREW ST2.9*8
16	TAPPING SCREW ST4.8*22	43	CARBON BRUSH
17	SPINDLE LOCK	44	BRUSH HOLDER
18	SPINDLE LOCK SPRING	45	COIL SPRING
19	GEAR BOX	46	CABLE CLAMP
21	NUT M6	47	NAME PLATE
22	PINION	48	SPRING
23	BEARING 629	49	SWITCH POLE
24	O RING (30*26*2)	50	SWITCH TRIGGER
25	MIDDLE COVER	51	HANDLE
26	ROTOR	52	WRENCH
27	ROTOR DUST COVER	53	ALLEN KEY
28	BEARING 626		

UK-EN20181214