



УШМ-95110

NO.	DESCRIPTION	NO.	DESCRIPTION
1	OUTSIDE FLANGE	28	BEARING
2	INNER FLANGE	29	RUBBER BUSH
3	SCREW M4X10	30	FAN GUIDE
4	SPRING WASHER	31	SCREW M4X55
5	PRESSURED BOARD	32	STATOR
6	PROTECTIVE GUARD	33	RIVET
7	WOODRUFF KEY 3X3.7X10	34	CARBON BRUSH
8	OUTPUT SPINDLE	35	BRUSH HOLDER
9	SCREW M4X12	36	PLASTIC HOUSING
10	FORE COVER	37	INDUCTOR
11	BEARING	38	CAPACITOR
12	BEARING COVER	39	SCREW ST2.9X9.5
13	SCREW M4X8	40	CAPACITOR PRESS BAR
14	BIG GEAR	41	LINK POLE
15	CIRCLIP FOR SHAFT 10	42	BACK HOUSING
16	BUSH	43	SCREW ST4.2X16
17	GEAR BOX	44	NAME PLATE
18	SCREW ST4.2X20	45	CABLE PLUG
19	"E"RING 6	46	RUBBER SLEEVE
20	SPRING	47	SPRING
21	BRAKE PIN	48	CORD CLIP
22	SIDE HANDLE	49	SCREW ST4.2X13
23	SMALL GEAR	50	SWITCH
24	BEARING	51	TRIGGER
25	BEARING COVER	501	SPANNER
26	SCREW M4X8	502	DISC
27	ARMATURE		

080820-1