



### УШМ-9512Д

NO.	DESCRIPTION	NO.	DESCRIPTION
1	OUTSIDE FLANGE	25	SMALL GEAR
2	INNER FLANGE	26	BEARING COVER
3	SCREW M4X8	27	WOODRUFFKEY3X3.7X10
4	SPRING WASHER	28	ARMATURE
5	PRESSURED BOARD	29	BEARING
6	WAVE SHAP SPRING	30	RUBBER BUSH
7	PROTECTIVE GUARD	31	FAN GUIDE
8	WOODRUFFKEY4X5X13	32	SCREW ST4X60
9	OUTPUT SPINDLE	33	STATOR
10	SCREW M4X12	34	NAME PLATE
11	FORE COVER	35	SCREW ST 3.5X10
12	SPRING	36	SWITCH
13	POSITION PIN	37	RIGHT HANDLE
14	BEARING	38	CAPACITOR
15	BEARING COVER	39	CORD
16	SCREW M4X10	40	RUBBER SLEEVE
17	BIG GEAR	41	LEFT HANDLE
18	CIRCLIP FOR SHAFT 10	42	CORD CLIP
19	BUSH	43	SCREW ST4.2X13
20	SCREW ST4X19	44	PLASTIC HOUSING
21	GEAR BOX	45	BRUSH HOLD
22	"E"RING 4	46	CARBON BURSH
23	BRAKE PIN	501	SPANNER
24	SIDE HANDLE	502	DISC

RU080820-1