



УШМ-9512Л

NO.	DESCRIPTION	NO.	DESCRIPTION
1	OUTSIDE FLANGE	24	BEARING COVER
2	INNER FLANGE	25	ARMATURE
3	SCREW M4X10	26	BEARING
4	SPRING WASHER	27	RUBBER BUSH
5	PRESSURED BOARD	28	FAN GUIDE
6	PROTECTIVE GUARD	29	SCREW ST4X60
7	WOODRUFF KEY 3X3.7X10	30	STATOR
8	OUTPUT SPINDLE	31	NAME PLATE
9	SCREW M4X12	32	SCREW ST3.5X10
10	FORE COVER	33	SWITCH
11	BEARING	34	RIGHT HANDLE
12	BEARING COVER	35	CORD
13	SCREW M4X10	36	RUBBER SLEEVE
14	BIG GEAR	37	LEFT HANDLE
15	CIRCLIP FOR SHAFT 10	38	CORD CLIP
16	BUSH	39	SCREW ST4.2X13
17	SCREW ST4X16	40	PLASTIC HOUSING
18	GEAR BOX	41	BRUSH HOLD
19	"E"RING 4	42	RIVET
20	SPRING	43	CARBON BRUSH
21	BRAKE PIN	44	CAPACITOR
22	SIDE HANDLE	501	SPANNER
23	SMALL GEAR	502	DISC

080820-1