



ФР-11171

NO.	DESCRIPTION	NO.	DESCRIPTION	NO.	DESCRIPTION
1	SCREW	34	NUT	67	CABLE
2	TOP COVER	35	LEFT HANDLE COVER	68	CABLE SLEEVE
3	SOFT START	36	SCREW	69	CABLE CLAMP
4	SCREW	37	SPEED REGULATOR	70	RIGHT HANDLE COVER
5	HOUSING	38	WIRE SHIELD B	71	CAPACITOR
6	BRUSH HOLDER	39	SCREW	72	SPINDLE LOCK
7	CARBON BRUSH	40	SPRING WASHER	73	SPIRING
8	BRUSH CAP	41	PLAIN WASHER	74	GEAR BOX
9	LOGO PLATE	42	LEFT HANDLE	75	FORE LOCK
10	DADE PLATE	43	RULER LOCKING KNOB	76	PLAIN WASHER
11	RULER KNOB	44	RULER BRUSH	77	SCREW
12	STATOR	45	PIPE CIRCLIP	78	GUIDE RACK
13	SCREW	46	TWIST SPRING	79	RACK PAD
14	WIND GUIDE	47	LOCKING SCREW	80	SCREW
15	FLEXIBLE SLEEVE	48	LOCKING KNOB	81	GUIDE ROD
16	SPRING	49	PLAIN WASHER	82	TEMPLATE GUIDE
17	GUIDE PIPE	50	SPRING WASHER	83	SPANNER
18	LOCKING KNOB 1	51	SCREW	84	CENRTING PIN
19	KNOB SPRING 1	52	RULER	85	COPY FOLLOWER
20	STEEL BALL	53	STATIC ADJUSTER	86	KNOB SPRING 2
21	SPRING	54	RULER SPRING	88	SCREW
22	SCREW	55	DYNAMIC ADJUSTER		
23	SCREW	56	BEARING 629		
24	STEEL SLEEVE	57	ROTOR		
25	DEPTH STOP	58	ROTOR LOCKING NUT		
26	BASE PLATE	59	COLLET SPRING		
27	SCREW	60	COLLET		
28	SCREW	61	COLLET NUT		
29	TRANSPARENT BAFFLE	62	BEARING PLATE		
30	SCREW	63	BEARING 6004-2RS		
31	BASE	64	RIGHT HANDLE		
32	DUST EJECTOR B	65	WRIE SHIELD A		
33	DUST EJECTOR A	66	SWITCH		