



## AG-9011X

| NO. | DESCRIPTION             | NO. | DESCRIPTION            |
|-----|-------------------------|-----|------------------------|
| 1   | OUTER FLANGE            | 26  | ROLLING BEARING 629    |
| 2   | GRINDING WHEEL          | 27  | BEARING COVER          |
| 3   | INNER FLANGE            | 28  | ROTOR                  |
| 4   | NUT                     | 29  | ROLLING BEARING 627    |
| 5   | WHEELCOVER              | 30  | BEARING BUSHING        |
| 6   | HEX SCREW M5X20         | 31  | WIND GUARD             |
| 7   | OUTPUT SPINDLE          | 32  | SWITCH POLE            |
| 8   | WOODRUFFKEY 3X10        | 33  | TAPPING SCREW ST4.2X60 |
| 9   | SCREW M4X14             | 34  | STATOR                 |
| 10  | SPRING WASHER 4         | 35  | SWITCH BUTTON          |
| 11  | PLAIN WASHER 4          | 36  | HOUSE                  |
| 12  | FORE COVER              | 37  | TAPPING SCREW ST3X8    |
| 13  | ROLLING BEARING 6000    | 38  | CARBON BRUSH HOLDER    |
| 14  | BEARING COVER           | 39  | CARBON BRUSH           |
| 15  | PLAIN HEAD SCREW M4X10  | 40  | CAPACITOR              |
| 16  | BIG GEAR                | 41  | SWITCH                 |
| 17  | CIRCLIP FOR SHAFT       | 42  | CABLE CLIP             |
| 18  | OGALLAY BEARING         | 43  | TAPPING SCREW ST4.2X1  |
| 19  | CIRCLIP FOR LOCKING PIN | 44  | TAPPING SCREW ST4.2X1  |
| 20  | SIDE HANDLE             | 45  | TRADE MARK             |
| 21  | GEAR BOX                | 46  | REAR COVER             |
| 22  | TAPPING SCREW ST4.2X20  | 47  | CABLE SLEEVE           |
| 23  | SELF-LOCKING PIN        | 48  | CABLE & PLUG           |
| 24  | SELF-LOCKING SPRING     | 49  | SPANNER                |
| 25  | PINION GEAR             |     |                        |

BM20110323