



AG1014P

NO.	DESCRIPTION	NO.	DESCRIPTION
1	FLANGE NUT	28	SCREW
2	POLISHING & GRINDING WHEEL	29	STATOR
3	GUARD	30	TENSION SPRING
3-1	BOLT	31	HOUSING
3-2	NUT	32	LABEL
4	FLAT KEY	33	NAMEPLATE
5	SPINDLE	34	BRUSH HOLDER
6	ANTI-DUST COVER	35	CARBON BRUSH
7	SCREW	36	BRUSH HOLDER COVER
8	SPRING WASHER	38	CORD GUARD
9	FRONT COVER	39	CORD&PLUG
10	BEAIRNG 6201Z	40	VARIABLE SPEED SWITCH
11	CIRCLIP	41	RIVET
12	WOODRUFF KEY	42	SMALL SPRING
13	BIG GEAR	43	SWITCH
14	CIRCLIP	44	CORD CLAMP
15	NEEDLE BEARING HK0810	45	SCREW
16	SELF-LOCK PIN	46	CAPACITOR
17	SCREW	48	SCREW
18	SCREW	49	SCREW
19	SPRING WASHER	50	NUT
20	GEAR BOX	51	CONNECTING LEVER
21	SPRING	52	WRENCH 24MM
22	SELF-LOCK BUTTON	53	SIDE HANDLE
23	BEARING RETAINER	54	ALLEN KEY
24	ROTOR	55	SCREW
25	INSULATION WASHER	56	WRENCH 13MM
26	BEARING 608Z	888	HANDLE ASSEMBLE
27	BUFFLE PLATE		

ST20120817

Sturmi!