



AG8150S

NO.	DESCRIPTION	NO.	DESCRIPTION
1	SIDE HANDLE	38	STATOR
2	SCREW M6X45	39	INDUCTOR
3	SPRING WASHER	40	SCREW ST4X26
4	PLAIN WASHER	41	SCREW ST4X18
5	LEFT PROTECTIVE GUARD	42	SOFT HANDLE COVER
6	OUTSIDE FLANGE	43	PLAIN WASHER
7	WASHER	44	SPRING WASHER
8	INNER FLANGE	45	SCREW M10X48
9	RIGHT PROTECTIVE GUARD	46	CARBON BRUSH
10	SCREW M6X27	47	CARBON BRUSH COVER
11	PLASTIC BUSH	48	SCREW ST4X12
12	OUTPUT SPINDLE	49	BRUSH HOLDER
13	WOODRUFF KEY	50	"E" RING 7
14	SCREW M4X14	51	ROLL WHEEL
15	SPRING WASHER	52	ROLL WHEEL SHAFT
16	FRONT COVER	53	SCREW M6X26
17	BEARING 6201RS	54	PLASTIC HOUSING
18	CIRCLIP	55	NAME PLATE
19	GEAR	56	PCB
20	CIRCLIP FOR SHAFT 12	57	SCREW ST 4X26
21	NEEDLE BEARING HK0810	58	CAPACITOR
22	GEARBOX	59	SWITCH
23	SCREW ST4X24	61	CORD & PLUG
24	"E" RING 6	62	CORD SLEEVE
25	SPRING	63	SCREW ST4X14
26	LOCK PIN	64	CORD CLIP
27	NUT	65	DUST EXTRACTOR
28	GEAR	66	PRESSING RING
29	BEARING 6000Z	67	SEALING RING
30	BEARING COVER	68	CURVED CONNECTION TUBE
31	SCREW M4X8	69	SEALING RING
32	ROTOR	70	CONNECTION SLEEVE
33	BEARING 608Z	71	KNOB
34	RUBBER BUSH	72	RUBBER WASHER
35	MAGNETIC RING	73	DEPTH ADJUSTING SET
36	FAN GUIDE	74	BLADE
37	SCREW	888	HOUSING ASSEMBLY

ST20120327