



## AG9012M

| NO. | DESCRIPTION          | NO. | DESCRIPTION            |
|-----|----------------------|-----|------------------------|
| 1   | OUT PRESS PLATE      | 29  | SCREW ST4.2*65         |
| 2   | IN PRESS PLATE       | 30  | STATOR                 |
| 3   | WHEEL GUARD          | 31  | Y CONNECTION BUCKLE4.2 |
| 4   | DUSTPROOF RING       | 32  | INSERT SPRING 2.8      |
| 5   | OUTPUT SPINDLE       | 33  | TERMINAL CAP           |
| 7   | SCREW M4*12          | 34  | HOUSING                |
| 8   | HEAD COVER           | 35  | SCREW ST3*10           |
| 9   | BEARING 6201         | 36  | CARBON BRUSH           |
| 10  | CIRCLIP FOR HOLE     | 37  | SPRING                 |
| 11  | BIG GEAR             | 38  | CARBON BRUSH SHELF     |
| 13  | BEARING 696          | 39  | SWITCH                 |
| 14  | SELF-LOCK PIN        | 40  | CORD ANCHOR            |
| 15  | SCREW ST4*20         | 41  | SCREW ST4*16           |
| 16  | HEAD SHELL           | 42  | CORD SLEEVE            |
| 17  | SELF-LOCK SPRING     | 43  | BACK COVER             |
| 18  | SELF-LOCK CAP        | 44  | SCREW ST3*10           |
| 19  | BEARING COVER        | 45  | CORD                   |
| 20  | NUT M6               | 46  | WRENCH                 |
| 21  | SCREW M4*10          | 47  | LEATHER RING           |
| 22  | SMALL GEAR           | 48  | LEATHER RING           |
| 23  | BEARING 629          | 49  | WASHER                 |
| 24  | ARMATURE             | 50  | SIDE HANDLE            |
| 25  | SMALL DUSTPROOF RING | 51  | PUSHBUTTON             |
| 26  | BEARING 607          | 52  | PUSHROD                |
| 27  | BEARING COVER        | 53  | EXTENSION SPRING       |
| 28  | BREAK WIND RING      |     |                        |

RU-ST20140904

Sturmi!  
POWER • GAS • HAND • TOOLS