



NO.	DESCRIPTION	NO.	DESCRIPTION
1	SCREW	27	BEARING 6201Z
2	SPRING	28	BEARING COVER
3	CIRCLIP	29	ROTOR
4	WASHER	30	BEARING 608Z
5	GEAR BOX	31	BUSH
6	SELF-OIL BUSH	32	STATOR
7	LOCK PIN	33	SCREW
8	CIRCLIP	34	ELECTRIC RING
9	GEAR	35	HOUSING
10	SCREW	36	NAME PLATE
11	WASHER	37	INDUCTOR
12	BEARING COVER	38	BRUSH HOLDER
13	BEARING 6202Z	39	WIND GUARD
14	GEAR BOX COVER	40	CARBON BRUSH
15	SPRING WASHER	41	BRUSH HOLDER CAP
16	SCREW	43	CORD SLEEVE
17	SPINDLE	44	PLUG & CORD
18	KEY	45	CORD CLAMP
19	SCREW	46	SCREW
20	WHEEL GUARD	47	SWITCH
21	NUT	48	CAPACITOR
22	INNER FLANGE	50	SCREW
23	GRINDER DISC	51	SIDE HANDLE
24	OUTSIDE FLANGE	888	HANDLE ASSEMBLY
25	NUT		
26	PINION		

ST20101207-01