



AS3548F

NO.	DESCRIPTION	NO.	DESCRIPTION
1	SHAFT SLEEVE	21	TORQUE SETTING RING
2	FRONT HOUSING(RIGHT)	22	POLE PLATE
3	INNER TEETH SLEEVE(PLASTIC)	23	POLE PLATE
4	PLAT WASHER	24	CLIP SHEET
5	INNER TEETH SLEEVE	25	SOCKET
6	WASHER	26	BATTERY CONNECTION PLATE
7	INSERT PIN	27	BATTERY-PACK COVER
8	REAR HOUSING	28	WASHER
9	BATTERY	29	SCREW
10	SWITCH ASS.	30	BATTERY-PACK HOUSING
11	MOTOR	31	PIN COVER
12	GEAR BOX COVER	32	FLEXING SHEET
13	PLAT WASHER	33	ROTATION FRICTION SHEET
14	PLASITC SHEET	34	FRONT HOUSING(LEFT)
15	WASHER SLEEVE	35	SPRING
16	GEAR BOX	36	STEEL BALL
17	OUTPUT SHAFT	37	PLANET GEAR
18	SMALL WASHER	38	CENTRAL BRACKET
19	SMALL WASHER	39	SCREW
20	CIRCLIP	40	STEEL NEEDLE