



BC1214

NO.	DESCRIPTION
1	JUMP STARTER SOCKET
2N	UP COVER
3	DOWN COVER
4	JUMP STARTER SOCKET COVER
5	BUTTON
6	BATTERY STATUS INDICATOR
7	LED
8	LED LENS
9N	PCB & USB ASSEMBLY
10	LI BATTERY

UK-ST20180604

POWER • GAS • HAND • TOOLS

POWER • GAS • HAND • TOOLS