



## BD7050

NO.	DESCRIPTION	NO.	DESCRIPTION
1	CHUCK	40	CLAMP-COLUMN
2	SHAFT	41	CLAMP-COLUMN
3	SPINDLE	42	WORM-ELEVATION
4	BEARING	43	TABLE BRACKET
5	BUSHING	44	HANDLE
6	RUBBER WASHER	45	V-BELT
7	BEARING	46	MOTOR PULLEY
8	WASHER	47	NUT
9	SNAP RING	48	MOTOR
10	SNAP RING	49	WASHER
11	BEARING	50	SPRING WASHER
12	BEARING	51	NUT
13	SQUARE KEY	52	WASHER
14	V-BELT	53	SCREW
15	NUT	54	RUBBER-WASHER
16	SNAP RING	55	BOLT
17	BEARING	56	KNOB
18	CIRCLE RING	57	RING-DEPTH STOP W/SCALE
19	BEARING	58	FEED SHAFT
20	PULLEY	59	HANDLE BAR
21	PULLEY-ADJUSTING	60	KNOB
22	PULLEY	61	BOLT
23	NUT	62	SCREW
24	SPRING WASHER	63	KNOB
25	MICRO-SWITCH	64	SPRING
26	PULLEY COVER	65	SLID BAR
27	SCREW	66	SHOCK-REDUCING RUBBER
28	ELECTROMAGNETIC SWITCH	67	MOTOR BASE
29	LOCK NUT	68	BOLT
30	NUT	69	WASHER
31	SPRING HOLDER	70	TIGHTENING BOLT
32	COIL SPRING	71	COLLAR-RACK
33	NUT	72	SUPPORT-COLUMN
33-1	CAPACITOR	73	RACK
34	CORD NIP	74	BOLT
35	CORD&PLUG	75	WASHER
35A	CORD ANCHORAGE	76	BASE
36	TABLE	77	GEAR
37	BOLT	78	GEAR SHAFT
38	SPRING WASHER	79	CASE
39	TABLE BRACKET	80	CASE SCREW&NUT