



## BG6022A

NO.	DESCRIPTION	NO.	DESCRIPTION
1	WHEEL LOCK NUT	28	ROTOR
2	WHEEL FLANGE	29	BOLT
3	OUTER WHEEL FLANGE	30	STATOR
4	WET WHEEL	31	CABLE
5	INNER WHEEL FLANGE	32	SCREW
6	JOURNAL BEARING	33	CABEL SLEEVE
7	BOLT	34	CORD SLEEVE
8	WASHER	35	MIDDLE RING
9	WASHER	36	SWITCH
10	WATER TANK	37	SWITCH PLATE
11	RUBBER CORK	38	CABLE PROTECTOR
12	BOLT	39	NAMEPLATE
13	COVER PLATE	40	WORK HANDLE
14	BOLT	41	WASHER
15	WASHER	42	WASHER
16	WASHER	43	TOOL REST
17	WORM	44	INNER GUARD
18	PIN	45	SQUARE NECK SCREW
19	WORM WHEEL	46	NAMEPLATE OF WHEEL
20	JOURNAL BEARING	47	WHEEL
21	SHORT AXIS	48	WINDING
22	RUBBER FEET	49	OUTER GUARD
23	BASE PLATE	50	BOLT
24	LEFT MAIN BODY	51	EYESHIELD
25	CAPACITOR	52	EYESHIELD BRACKET
26	SCREW	53	WORM GEAR CASE
27	BEARING 6202		

RU090729-4