



ENGINE FOR BP87101

| NO. | DESCRIPTION | NO. | DESCRIPTION | NO. | DESCRIPTION |
|------|-------------------------------|-----|-----------------------------|-----|---------------------------|
| 1 | BOLT | 39 | GOVERNOR WEIGHT HOLDER COMP | 81 | RECOIL STARTER REEL |
| 2 | VENT-PIPE | 40 | GOVERNOR HOLDER CLIP | 82 | RECOIL STARTER ROPE |
| 3 | HEAD COVER COMP | 41 | GOVERNOR COVER | 83 | RECOIL STARTER KNOB |
| 4 | HEAD COVER PACKING | 42 | NUT | 84 | RECOIL STARTER COMP |
| 5 | PIVOT ADJUSTING NUT | 43 | OIL SENSOR ASSEMBLY | 85 | FLANGE BOLT M6×8 |
| 6 | ROCKER ARM PIVOT | 44 | BOLT | 86 | FUEL TANK CAP |
| 7 | VALVE ROCKER ARM | 45 | FIXED PIN | 87 | SEALING RING |
| 8 | PIVOT BOLT | 46 | WOODRUFF KEY | 88 | STEEL BUSH |
| 9 | PUSH ROD GUIDE PLATE | 47 | CAMSHAFT ASSEMBLY | 89 | FILTER |
| 10 | VALVE ROTATOR | 48 | CRANKSHAFT ASSEMBLY | 90 | FUEL TUBE |
| 11-1 | EXHAUST VALVE SPRING RETAINER | 50 | PAPER GASKET | 91 | FUEL NUZZLE |
| 11-2 | INTAKE VALVE SPRING RETAINER | 52 | OIL FILLER CAP PACKING | 92 | BOLT |
| 12 | VALVE SPRING | 53 | OIL FILLER CAP ASSEMBLY | 93 | FUEL TANK |
| 14 | FLANGE BOLT M8×55 | 54 | CRANKCASE COVER | 94 | NUT |
| 15 | SPARK PLUG | 55 | OIL SEAL | 95 | GOVERNOR ROD |
| 16 | CYLINDER HEAD COMP | 56 | BOLT | 96 | GOVERNOR SPRING |
| 17 | NUT | 57 | CRANKCASE | 97 | THROTTLE RETURN SPRING |
| 18 | MUFFLER COMP | 58 | DRAIN BOLT WASHER | 98 | GOV.SETTING COMP. |
| 19 | WASHER | 59 | DRAIN PLUG BOLT | 99 | BOLT |
| 20 | STUD BOLT | 60 | FLYWHEEL GUARD | 100 | GOVERNOR ARM |
| 21 | BOLT | 61 | CLIP | 101 | NUT |
| 22 | WIND FENDER | 62 | DIODE COMP | 102 | BOLT |
| 23 | CYLINDER HEAD GASKET | 63 | BOLT | 103 | LOCK PIN |
| 24-1 | INTAKE VALVE | 64 | BOLT | 104 | WASHER |
| 24-2 | EXHAUST VALVE | 66 | IGNITOR COMP | 105 | GOVERNOR ARM SHAFT |
| 25 | PULL ROD | 67 | FLYWHEEL | 106 | STUD BOLT |
| 26 | VALVE LIFTER | 68 | BOLT | 107 | WASHER |
| 27 | PISTON RING ASSEMBLY | 69 | COOLING FAN | 108 | CARBURETOR INSULATOR |
| 28 | PISTON PIN | 70 | START HUB | 109 | CARBURETOR PACKING |
| 29 | PISTON PIN CLIP | 71 | NUT | 110 | CARBURETOR ASSEMBLY |
| 30 | PISTON | 72 | FAN COVER COMP | 111 | CARBURETOR PACKING |
| 31 | CONNECTING ROD COMP | 73 | ENGINE SWITCH COMP | 112 | CARBURETOR WASHER |
| 32 | FIXED PIN | 74 | BOLT | 113 | NUT |
| 33 | DRAIN BOLT WASHER | 75 | SETTING SCREW | 114 | BOLT |
| 34 | DRAIN PLUG BOLT | 76 | RATCHET GUIDE | 115 | AIR CLEANER GENERAL ASSY. |
| 35 | BEARING 6205 | 77 | RATCHET GUIDE SPRING | 116 | NUT |
| 36 | CIRCLIP | 78 | STARTER RATCHET | | |
| 37 | GOVERNOR SHAFT | 79 | RETURN SPRING | | |
| 38 | GOVERNOR HOLDER CLIP | 80 | SPRING | | |

ST20130927