



BS8573

NO.	DESCRIPTION	NO.	DESCRIPTION
1	RIGHT HOUSING	27	CABLE CLAMP
2	SANDING BELTS	28	LEFT HOUSING
3	BOTTOM PLATE	29	WASHER
4	BODY	30	ADJUST-NUT
5	FRONT-WHEEL FRAME	31	SCREW
6	BIG SPRING	32	STATOR
7	SMALL SPRING	33	SCREW
8	REAR-WHEEL	34	FAN BAFFLE
9	WASHER	35	ROTOR
10	NEEDLE BEARING	36	SCREW
11	GEAR COVER	37	BEARING COVER
12	BEARING 626Z	38	BEARING 608Z
13	BIG GEAR	39	INNER COVER
14	CIRCLIP	40	SCREW
15	BRUSH BUSH	41	GEAR AXIS
16	BRUSH HOLDER	42	BAFFLE
17	CARBON-BRUSH SPRING	43	BEARING 627Z
18	CARBON-BRUSH	44	SCREW
19	BEARING 626Z	45	SMALL-BELT-WHEEL
20	BEARING BUSH	46	BELT
21	INDUCTOR	47	BIG-BELT-WHEEL
22	CIRCLIP	48	BELT COVER
23	WASHER	49	SCREW
24	SWITCH	50	NAME PLATE
25	CAPACITOR	51	CABLE SLEEVE
26	SCREW	52	CABLE&PLUG

RU5102501