



CC9930CL

NO.	DESCRIPTION	NO.	DESCRIPTION
1	BATTERY DIAL BUTTON	38	OIL NOZZLE
2	BATTERY DIAL BUTTON SPRING	39	SEAL RING
3	BATTERY DIAL BUTTON PIN	40	RETAINER RING
4	FIXED SUPPORTING	41	BIG GEAR WASHER
5	PLUG BOARD	42	GEAR WORM
6	SCREW 4X8	43	FAN COVER CAP
7	PCB BOARD	44	FAN COVER
8	HANGER	45	MOTOR
9	HANGER PRESSING PLATE	46	FRONT GUARD
10	TRIGGER SPRING	47	SCREW 3X8
11	TRIGGER	48	BRAKE SPRING PLATE
12	PUSHING ROD	49	TENSION DISC
13	ANTI SELF LOCK PUSHING BUTTON	50	SCREW 4X10
14	FRONT HANDLE	51	RIGHT HOUSING
15	LEFT HANDLE	52	RIGHT HANDLE
16	SCREW 4X16	53	PRESSING PLATE
17	SCREW 5X30	54	NUT M6
18	LEFT HOUSING	55	RIGHT HOUSING INSERT PARTS
19	OIL TANK CAP BUCKLE	56	SCREW M5X14
20	ROTATED PIN	57	SPROKET
21	PRESSURE SPRING	58	E RETAINER RING
22	OIL TANK CAP	59	SEAL RING
23	OIL TANK CAP SEAL RING	60	SPIKE BUMPER
24	HANGER	61	BAR SCREW
25	FLAT WASHER	62	12" GUIDE BAR
26	VALVE	63	PUSHING BLOCK
27	OIL TANK	64	12" SAW CHAIN
28	SCREW 3X10	65	BAR COVER
29	OIL TANK CONNECTOR BLOCK	66	SCREW 4X12
30	SPONGE FILTER	67	CAM
31	OIL TANK CONNECTOR	68	SPROKET COVER
32	OIL TANK SEALRING	69	ADJUSTING LINING
33	INLET PIPE 165MMØ6XØ3	70	ADJUSTING KNOB
34	SCREW 3X8	71	PRESSING KNOB
35	OIL PUMP ASSEMBLY		
36	INLET PIPE 170MMØ6XØ3		
37	SCREW 4X12		