

CD-3212LBB CD-3218LBB

NO.	DESCRIPTION	NO.	DESCRIPTION
1	CHUCK SCREW	35	ITWO SPEEDS CHANGE BUTTON
2	CHUCK	36	SPRING
3	TORQUE ADJUSTMENT RING	37	DRCORATION COVER
4	TORQUE ADJUSTMENT NUT	38	LOCK RING
5	SPRING	39	HOUSING
6	WASHER	40	SCREW
7	SPINDLE	41	ROPE
8	BEARING 688Z	42	SWITCH
9	STEEL BALL	43	DIRECTION SWITCH
10	PIN	44	BUCKLE
11	GEAR BOX	45	SCREW BIT HOLDER
12	BEARING 688Z	46	SCREW BITS
13	CIRCLIP	47	SPRING
14	THE THIRD PLANET BRACKET	48	MAGNET (ONLY FORДШ-3118ЛБ)
15	GEAR RING	49	BATTERY PACK
16	WASHER	49-1	BATTERY PACK COVER
17	THE THIRD PLANETARY GEAR	49-2	PCB
18	THE SECOND PLANETARY GEAR CARRIER	49-3	LOCK BUTTON
19	THE SECOND PLANETARY GEAR	49-4	SPRING
20	TWO SPEED CHANGE GEAR RING	49-5	SPONGE
21	PLASTIC GEAR RING	49-6	BATTERY CELL
22	SCREW	49-7	BATTERY BASE
23	SPINDLE LOCK BLOCK	49-8	SCREW
24	LOCK PIN	49-9	CONNECTION PIECE
25	THE FIRST PLANETARY GEAR CARRIE	49-10	CONNECTION BARCKET
26	THE FIRST PLANETARY GEAR	50	CHARGER
27	INNER GEAR RING	888	GEAR BOX ASSEMBLY
28	MOTOR GEAR	889	MOTOR ASSEMBLY
29	WASHER		
30	SCREW		
31	MOTOR PRESS BOARD		
32	MOTOR		
33	INTERNAL CABLE		
34	SHRAPNET		

