

CD3018M CD3014M

NO.	DESCRIPTION	NO.	DESCRIPTION
1	SCREW	30	2-SPEED STEEL WIRE
2	CHUCK	31	GEAR
3	TORQUE BUSH	32	FIXED GEAR RING
4	TORQUE RING	33	PLANET GEAR1
5	SPRING-REBOUND PLATE	34	WASHER
6	SCREW RING	35	SCREW
7	BIG SPRING	36	SPRING WASHER
8	CIRCLIP	37	MOTOR COVER
9	WASHER	38	MOTOR GEAR
10	STEEL BALL	39	MOTOR
11	WASHER	40	2-SPEED LEVER
12	STOP PIN	41	TAPPING SCREW
13	STEEL BALL	42	LED LIGHT
14N	BUSH	45	F/R LEVER
15N	GEAR BOX	46	SWITCH
22	INNER GEAR RING	47	CONNECTOR
23	PLANET GEAR	63	QUICK CHARGER
24	BIG WASHER	64	SPINDLE
25	2ND PLANET BRACKET	100	BATTERY PACK
26	PLANET GEAR2	101	GEAR BOX ASSEMBLY
27	MOVABLE GEAR	888	HOUSING ASSEMBLY
28	MIDDLE COVER		
29	TAPPING SCREW		

ST20140121

