



## MF5620CLQ

NO.	DESCRIPTION	NO.	DESCRIPTION
1	SUPPORTED FLANGE	28	E RING
2	FELT SEAL	29	BEARING 625
3	OUTPUT SPINDLE PIN	30	MIDDLE COVER
4	OUTPUT SPINDLE	31	BEARING 608
5	SEAL RING	32	BEARING 6000
6	CIRCLIP	33	CIRCLIP
7	WAVE WASHER	34	SCREW M4*10
8	BEARING 6001	35	MOTOR CONNECTOR
9	BEARING 6001 FOR TD9511-3	36	LED ASSY
10	SHIFTING FORK	37	LEFT HOUSING
11	REDUCER LEFT BRACKET	38	DRIVER SHAFT
12	REDUCER	39	MOTOR
13	SCREW M4*10	40	MOTOR BRACKET
14	SPRING	41	INDUCTANCE
15	SEAL RING	42	PCB ASSY
16	TIGHTENING BOLT	43	SCREW ST3*10
17	COVER GASKET	44	SWITCH SURPORT
18	CAM	45	SWITCH
19	TRIGGER	46	SWITCH LEVER
20	SPRING PIN M4*16	48	SCREW ST4*10
21	SCREW M3*6	49	BRACKET
22	TRIGGER PAD	50	RUBBER CUSHIONING1
23	BUCKLE	51	RUBBER CUSHIONING2
24	TD8501T-1 PIN	501	SCRAPER
25	STEEL BUSHING	502	SAW
26	SCREW M3*6	503	BASE SANDER
27	REDUCER RIGHT BRACKET	504	SANDER PAPER

UK-ST201200103