

## CF7324

	NO.	DESCRIPTION	NO.	DESCRIPTION
POWE	1	CROSS SCREW	50	SPRING WASHER
	2	FLAT WASHER	51	DENTATION WASHER
	3	RUBBER SUPPORT	52	SWING ARM
	4	METAL BASE	53	BLOCK OF THE DEPTH STOP
	5	HEXAGON NUT	54	SPRING WASHER
	6	VICE STAND	55	CROSS SCREW
	7	FLAT WASHER	56	STATOR
	8	SPRING WASHER — A	57	BEARING
	9	HEXAGON BOLT	58	ROTOR
	10	CIRCLIP FOR SHAFT	59	ANTI-WIND RING
	11	HANDWHEEL	60	BEARING
	12	POLE OF HANDWHEEL	61	LOCK PIN
	13	THREAD BAR	62	SPRING OF LOCK PIN
	14	SPEED NUT	63	GEAR BOX
	15	SPRINGINESS COLUMN PIN	63-1	SEALING RING
	16	FIXATION SCREW OF CHAIN	64	FIXED GUARD
	17	CHAIN	65	CROSS SCREW
	18	HEXAGON NUT	66	ACTIVE COVER
	19		67	
		FLAT WASHER		CROSS SCREW
	20	CROSS SCREW	68	AUTOMATIC GUARD
	21	V PIN	69	RUBBER WASHWER
	22	VICE NIP PLATE	70	HEXAGON BOLT
	23	VICE COLUMN PIN	71	BEARING
	24	CAP OF BRUSH HOLDER	72	CLIP
	25	CARBON BRUSH	73	GEAR
	26	BRUSH HOLDER	74	BEARING HOLDER
	27	SCALE PLATE	75	BEARING
	28	FLAT WASHER	76	WOODRUFF KEY
	29	SPRING WASHER	77	SPINDLE
	30	HEXAGON BOLT	78	FLANGE
	31	HEXAGON NUT	79	DISC
	32	HEXAGON BOLT	80	SMALL FLANGE
	33	HEXAGON NUT	81	HEXAGON BOLT
	34	BASE OF DEPTH STOP	82	WRENCH
	35	FLAT WASHER	83	CROSS SCREW
	36	SPRING WASHER	84	CROSS SCREW
	37	CROSS SCREW	85	CROSS SCREW
	38	HEXAGON NUT	86	CROSS SCREW
	39	ANTI-DUST BOARD	87	CROSS SCREW
	40	SPRING WASHER	88	CROSS SCREW
	41	INNER HEXAGON BOLT	89	SWITCH
	42	BIG SPRING	91	CROSS SCREW
	43	CIRCUMGYRATE PIN	92	CORD ANCHORAGE
	44	ANTI-DUST WASHER	93	CORD SLEEVE
	45	CONNECTING SCREW	94	HEXAGON NUT
	45	CROSS SCREW	96	CABLE & PLUG
	46	REAR COVER		
			888	HANDLE ASSEMBLE
	48	CROSS SCREW	AS	<ul> <li>HAND • TOOL</li> </ul>
	49	CROSS SCREW		

ST20101207-01