



CS50161

NO.	DESCRIPTION	NO.	DESCRIPTION
1	SOFT HANDLE COVER	34	KNOB FOR DEPTH ADJUSTMENT
2	RIGHT HANDLE	35	FIXED GUARD
3	CORD & PLUG	36	RIVING KNIFE
4	CORD SLEEVE	37	HEX SCREW
5	SCREW	38	MOVING GUARD
6	CORD ANCHORAGE	39	BEARING 6001
7	CAPACITOR	40	OUTPUT SHAFT
8	SWITCH	41	WOODRUFF KEY
9	LEFT HANDLE	42	BEARING COVER
10	REAR COVER	43	SCREW
11	DECORATED BOARD	44	INNER FLANGE
12	CARBON BRUSH	45	SAW BLADE
13	BRUSH COPPER NEST	46	OUTER FLANGE
14	BRUSH HOLDER	47	PLAIN WASHER
15	SCREW	48	HEX SCREW
16	SPRING WASHER	49	PULLING SPRING
17	HOUSING	50	SCREW
18	ELECTRIC CONNECT PIECE	51	SCREW
19	INDUCTOR	52	SCREW
20A	STATOR	53	RUBBER BLOCK
21	SCREW	54	CONNECTION SCREW
22	WIND GUARD	55	KNOB FOR ANGLE ADJUSTMENT (I)
23	BEARING 608	56	DEPTH STAND
24A	ROTOR	57	SCREW
25	BEARING 6000	58	BASE PLATE
27	CENTRAL SUPPORTER	59	RIVET
28	OILED BEARING	60	SCREW FOR FIXED PARALLEL GUIDE
29	CIRCLIP	61	ANGLE STAND
30	BIG GEAR	62	KNOB FOR ANGLE ADJUSTMENT (II)
31	BEARING BASE	63	SCREW
32	SPRING WASHER	64	SAFETY BLOCK
33	SCREW	65	TAPPING SCREW

ST20100611