



CS50200

NO.	DESCRIPTION	NO.	DESCRIPTION
1	LEFT HANDLE	38	SCREW
2	SCREW	39	MOVING GUARD
3	SCREW	40	WASHER
4	CORD&PLUG	41	CIRCLIP
5	SCREW	42	BLADE
6	CORD SLEEVE	43	BEARING 6201
7	SWITCH	44	CIRCLIP
8	CAPACITOR	45	MIDDLE COVER
9	SCREW	46	SCREW
10	RIGHT HANDLE	47	HEX BOLT
11	SCREW	48	WASHER
12	COVER	49	OUTER FLANGE
13	BEARING PRESSING SHEET	50	INNER FLANGE
14	ROTOR	51	PULL SPRING
15	BEARING 6201	52	SCREW
16	WAVE WASHER	53	SPRING HOOK
17	WIND GUARD	54	FORE COVER
18	STATOR	55	HEX NUT
19	HOUSING	56	RIVING KNIFE
20	TWIST SPRING	57	TOP HANDLE
21	NUT	58	DOWN HANDLE
22	SCREW	59	HEX BOLT
23	BRUSH HOLDER	60	ANGLE ADJUSTMENT BRACKET
24	CARBON BRUSH	61	RIGHT BRACKET
25	SCREW	62	RETAINING RING
26	SCREW	63	HEX SCREW
27	REAR COVER	64	DEPTH ADJUSTMENT BRACKET
28	SCREW	65	LONG WING BOLT
29	OIL STORAGE RING	66	WING BOLT
30	GEAR BOX	67	LEFT BRACKET
31	BEARING 629	68	RIVET
32	BIG GEAR	69	BASE PLATE
33	OUTPUT SHAFT	70	CONNECTION PIN
34	BEARING 6204	71	TWIST WASHER
35	CIRCLIP	72	SCREW
36	SCREW	73	WASHER
37	FIXED GUARD	74	WING NUT

RU60620-1