



## GB1926

NO.	DESCRIPTION	NO.	DESCRIPTION
1	screw M4*20	41	crank case
2	screw M4*25	42	screw M5*30
3	auxiliary handle	43	Fly wheel
4	starter	44	cushioning 3
5	cushioning 1	45	trigger
6	screw ST5*16	46	extinction conductor 2
7	Big cover	47	right housing
8	Dust cover	48	Flameout switch
9	cushioning 2	49	left handle
10	righth handle	50	bottom seat
11	Handle little cover	51	cushioning 4
12	fuel tank	52	Throttle line
13	screw M5*25	53	gasket
14	Intake-tube	54	Carburetor
15	gasket	55	Air filter
16	Wind deflector	56	screw M5*55
17	cylinder	57	Empty filter element
18	Spark plug	58	Air filter cover
19	screw M5*22	59	Air filter cover screw
20	gasket	60	steel tube
21	muffler	61	fan
22	screw M5*55	62	blade
23	Ignition	63	NUT M8*1
24	screw M4*20	64	Left housing
25	extinction conductor 1	65	switch
26	Bakelite gasket 4*10*4	66	safety set piece
27	gasket	67	Safety switch cover
28	piston ring	68	screw ST5*12
29	Piston	69	Inlet air shield
30	Piston pin	70	Torsional spring
31	Piston pin ring	71	washer $\phi 5^* \phi 16^* 1.5$
32	Needle roller bearing HK081112	72	PIN $\phi 3.5^* 48$
33	drive plate	73	vacuum tube A
34	Oil seal	74	vacuum tube B
35	crank case	75	screw M5*12
36	PIN $\phi 3^* 10$	76	bend tube
37	Bearing 6001	77	dust bag
38	crank shaft	78	Blower tube A
39	Woodruff key 3*10	79	Blower tube B
40	gasket	80	wind wheel base plate

UK-ST20230628