



## ID2010

NO.	DESCRIPTION	NO.	DESCRIPTION
No. 01	Left-threaded screw M*25	No. 20	Housing
No. 02	Chuck	No. 21	Carbon brush
No. 03	Output spindle	No. 22	On the Brush housing
No. 04	Steel Ball $\Phi 3$	No. 23	Roll Sprin
No. 05	Rolling bearing 6001-2Z	No. 24	Inductor
No. 06	Snap ring 10	No. 25	Forwarder/ reverse knob
No. 07	Driven gear	No. 26	SwitchFA2-4/1BEK
No. 08	Spring	No. 27	Capacitor 0.22uF 250V
No. 09	Wearing washer	No. 28	Cable protector
No. 10	needle bearing	No. 29	Cable
No. 11	Steel plate	No. 30	Under the brush holder
No. 12	Function shift knob	No. 31	Self-tapping screw ST3*10
No. 13	Central support bracket	No. 32	Self-tapping screw ST4*16
No. 14	Rolling bearing 608-2Z	No. 33	Right label
No. 15	Rotor	No. 34	Upper housing
No. 16	Rolling bearing 607-2Z	No. 35	Chuck key
No. 17	Bearig bushings	No. 36	Auxiliary handle
No. 18	Stator	No. 37	Depth stop
No. 19	Left lable		