



ID2176A

NO.	DESCRIPTION	NO.	DESCRIPTION
1	SCREW	20	BEARING HOLDER
2	BEARING HOLDER	21	BEARING 608
3	CHUCK	22	SIDE HANDLE
4	BOLT	23	SWITCH
5	HOOP	24	SCREW
6	DEPTH POLE	25	ROTOR
7	SCREW	26	BEARING 607
8	GEAR BOX	27	STATOR
9	SPINDLE	28	BRUSH HOLDER
10	WOODRUFF KEY	29	CARBON BRUSH
11	IMPACT SPRING	30	CARBON BRUSH
12	BEARING 6001	31	HOUSING
13	BEARING BOARD	32	SCREW
14	SCREW	33	CORD CLIP
15	CIRCLIP	34	CORD SLEEVE
16	GEAR	35	CORD & PLUG
17	CIRCLIP	36	CAPACITOR
18	CHANGE KNOB	37	INDUCTOR
19	BUSH		

ST20140717