



ID2199A

NO.	DESCRIPTION	NO.	DESCRIPTION
1	SCEW	23	STATOR
2	KEY	24	BEARING 607Z
3	KEY CHUCK	25	HOUSING
4	GEAR BOX	26	SCREW
5	SCEW	27	INDICATOR
6	SPINDLE	28	BRUSH HOLDER
7	SPRING	29	SPRING
8	BEARING 6001Z	30	CARBON BRUSH
9	BEARING PRESS BOARD	31	SCREW
10	SCEW	32	SWITCH
11	CIRCLIP	33	CABLE SLEEVE
12	KEY	34	CABLE CLAMP
13	GEAR	35	SCREW
14	CIRCLIP	36	CABLE
15	NEEDLE BEARING HK0810	37	CAPACITOR
16	CENTER BEARING BRACKET	38	SCREW
17	WOOL RING	39	HANDLE RING
18	PIN	40	DEPTH RULER
19	SPRING	41	HANDLE ROD
20	IMPACT/DRILL CHANGE KNOB	42	HANDLE
21	BEARING 608Z	999	HANDLE ASSEMBLY
22	ROTOR		

ST20140627

