



JS4171P

NO.	DESCRIPTION	NO.	DESCRIPTION	NO.	DESCRIPTION
1	SWITCH	32	NEEDLE BEARING HK0910	66	SPRING
3	SCREW	33	GEAR	67	PENDULUM SWITCH KNOB
4	CORD & PLUG	34	FLAT WASHER	68	WIND GUARD
5	CORD SLEEVE	35	GEAR SHAFT	69	SCREW
6	CORD CLAMP	36	INDUCTOR	70	STATOR
7	SCREW	37	BEARING BUSH	71	SCREW
8	CAPACITOR	38	BEARING 607Z	72	BASE COVER
9	COLUMN PIN	39	ROTOR	73	BASE
10	SWITCH TRIGGER	40	BEARING 608Z	74	BASE CLAMP
11	POSITION PIN	41	SCREW	75	HEX BOLT
12	COMPRESSION SPRING	42	FLAT WASHER	76	HOUSING
13	LOCK BUTTON	43	GEAR BOX	77	CARBON BRUSH
14	VARIABLE SPEED SWITCH	44	PAPER WASHER	78	BRUSH HOLDER
15	SCREW	45	CIRCLIP	79	REAR COVER
16	ROLLER ROCKET PIN	46	SCREW	80	SCREW
17	ROLLER ROCKET	47	SPRING	81	TRANSPARENT GUARD
18	ROLLER PIN	48	COLUMN PIN	101	ANTI-DUST WASHER
19	ROLLER	49	COLUMN PIN	102	SCREW
20	CIRCLIP	50	RUBBER WASHER	103	GUIDE RULER
21	SCREW	51	COLUMN PIN	104	SCREW
22	GEAR BOX COVER	52	SCREW	105	SAW BLADE BRACKET
23	RECIPROCATING BAR CLAMP	53	SCREW	106	CIRCLIP
24	YOKE	55	BOW	107	WASHER
25	SCREW	56A	RECIPROCATING ROD	108	QUICK CHANGE BLADE BUTTON
26	BUSH	60	RUBBER WASHER	109	SPRING
27	CAM	61	FLAT WASHER	110	STEEL BALL
28	FLAT WASHER	62	CIRCLIP	888	HANDLE ASSEMBLE
29	BALANCE BLOCK	63	RUBBER PROTECTOR	999	ROLLER ASSEMBLE
30	BALANCE BLOCK	64	STEEL FRAME		
31	FORK LEVER	65	STEEL BALL		

ST20130930-05