



# JS4171P

NO.	DESCRIPTION	NO.	DESCRIPTION	NO.	DESCRIPTION
1	SWITCH	31	FORK LEVER	61	FLAT WASHER
3	SCREW	32	NEEDLE BEARING HK0910	62	CIRCLIP
4	CORD & PLUG	33	GEAR	63	RUBBER PROTECTOR
5	CORD SLEEVE	34	FLAT WASHER	64	STEEL FRAME
6	CORD CLAMP	35	GEAR SHAFT	65	STEEL BALL
7	SCREW	36	INDUCTOR	66	SPRING
8	CAPACITOR	37	BEARING BUSH	67	PENDULUM SWITCH KNOB
9	COLUMN PIN	38	BEARING 607Z	68	WIND GUARD
10	SWITCH TRIGGER	39	ROTOR	69	SCREW
11	POSITION PIN	40	BEARING 608Z	70	STATOR
12	COMPRESSION SPRING	41	SCREW	71	SCREW
13	LOCK BUTTON	42	FLAT WASHER	72	BASE COVER
14	VARIABLE SPEED SWITCH	43	GEAR BOX	73	BASE
15	SCREW	44	PAPER WASHER	74	BASE CLAMP
16	ROLLER ROCKET PIN	45	CIRCLIP	75	HEX BOLT
17	ROLLER ROCKET	46	SCREW	76	HOUSING
18	ROLLER PIN	47	SPRING	77	CARBON BRUSH
19	ROLLER	48	COLUMN PIN	78	BRUSH HOLDER
20	CIRCLIP	49	COLUMN PIN	79	REAR COVER
21	SCREW	50	RUBBER WASHER	80	SCREW
22	GEAR BOX COVER	51	COLUMN PIN	81	TRANSPARENT GUARD
23	RECIPROCATING BAR CLAMP	52	SCREW	101	ANTI-DUST WASHER
24	YOKE	53	SCREW	102	SCREW
25	SCREW	55	BOW	103	GUIDE RULER
26	BUSH	56	RECIPROCATING ROD	104	SCREW
27	CAM	57	SCREW	105	SAW BLADE BRACKET
28	FLAT WASHER	58	SCREW	888	HANDLE ASSEMBLY
29	BALANCE BLOCK	59	BLADE CHUCK	999	ROLLER ASSEMBLY
30	BALANCE BLOCK	60	RUBBER WASHER		

ST20130314-04

